



ALTAN P (NONYLPHENOL ETHOXYLATE FREE)

COMPOSITION:

ALTAN P IS COMPOUNDED PICKLING AGENT WITH VERY GOOD PENETRATING POWER AND IS DESIGNED TO SOLVE THE STIFFNESS IN BACK AND NECK AREA. ALTAN P WHEN APPLIED IN CONJUNCTION WITH EUREKANOL 821 WILL RESULT IN VERY UNIFORM SOFTNESS AND FULL WET BLUE ACROSS THE ENTIRE HIDE.

APPLICATION:

A. ALTAN P IS ONLY APPLICABLE IN THE PICKLING BATH IMMEDIATELY AFTER SALT WITH DOSAGE OF 1-2% DEPENDS ON PELT THICKNESS.

PROPERTIES:

APPEARANCE: WATER CLEAR LIQUID
ANALYSIS: pH 8.2-8.8
ACTIVE INGREDIENT: 40.5-42%

PACKING: 120KGS/150KGS RECONDITIONED PLASTIC DRUMS

This information is based on our current state of knowledge and experience and without any obligations on our part.

Technical advice given to customers in written forms or by trials do not absolve the customer, on the account of outside influences which may have an effect on the results of testing or trials.

ALTAN P (NONYLPHENOL ETHOXYLATE FREE) P-2

PICKLING OF GARMENT LEATHER:

50%	WATER	25C	
8-10%	SALT		
1.5%	ALTAN MS		20'
1%	ALTAN P		30'
0.7%	SULFURIC ACID (1:10)		90' pH 3.2-3.4
0.5%	EUREKANOL 821 (1:4)		30'
0.5%	EUREKANOL 821 (1:4)		30'
0.5%	EUREKANOL 821 (1:4)		30'
0.5%	EUREKANOL 821 (1:4)		30'

OVER NIGHT, EVERY 120' RUN 20' TILL MORNING AND NEXT DAY CARRY
CHROME TANNING AS USUAL

FOR SHOE UPPER, THE SAME PICKLING COULD BE USED:

RECHROMING APPLICATION:

WASHING:

100%	WATER	40C	
1%	ALCHEM CSAM		

DRAIN & WASH:

100%	WATER	35C	10'
2%	EUREKANOL MIW		20'
6%	CHROME POWDER		
2%	ALTAN MS		30'
0.2%	ALTAN M		120'

This information is based on our current state of knowledge and experience and without any obligations on our part.

Technical advice given to customers in written forms or by trials do not absolve the customer, on the account of outside influences which may have an effect on the results of testing or trials.